

# **Quick Start Guide**

# **BoostLynx**<sup>TM</sup> Series Evaluation Board Documentation

The BoostLynx™ series evaluation board (BOOST\_PROLYNX\_EVAL) Board comes with an assembled module and test components

Pre-Installed components for the BoostLynx<sup>TM</sup> include input filtering [ $C_{25}$  (0.047uF,50V), C22, 24, 26 & 38(10uF,50V), output filtering [ $C_{34}$ (0.1uF,50V),  $C_{27,29,31,32,33,8131}$ (10µF,50V)], Trim Resistor R5 = 10.5K $\Omega$  and some test points.




Figure 1. Power and Analog Signal Interface for the ABXS002/001 Eval Board



# **Quick Start Guide**

Caution! Before applying power, make sure that the externally installed capacitors (input & output) have appropriate voltage and polarity ratings based on the application.

#### Notes:

• Module can be trimmed either by soldering a different fixed resistor(s) @ R5 or by attaching a potentiometer/resistor between test points E11 and E35.

### **Contact Us**

For more information, call us at 1-877-546-3243 (US) 1-972-244-9288 (Int'l)



## **OmniOn Power Inc.**

601 Shiloh Rd. Plano, TX USA

## omnionpower.com

We reserve the right to make technical changes or modify the contents of this document without prior notice. OmniOn Power does not accept any responsibility for errors or lack of information in this document and makes no warranty with respect to and assumes no liability as a result of any use of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents – in whole or in parts – is forbidden without prior written consent of OmniOn Power. This document does not convey license to any patent or any intellectual property right. Copyright© 2023 OmniOn Power Inc. All rights reserved.